

# 5V Dual USB Output Li-ion Power Bank

Specific to Tablet PC

Instruction Manual




## 1. Product Introduction

Thank you for purchase this 5V Dual Output USB Power Bank. Prior to using this battery, we strongly recommend you to read this instruction manual carefully and keep it for future reference. This is a universal, portable and chargeable power source which is designed for various digital mobile devices. The high current output (5V/2.1A) is special designed for Tablet PC. The multiple protection circuits make this product more safety. And the casing of this product is made by high strength plastic, to avoid damage when drop down. We sure that it will make your digital devices more powerful and last a longer time.

## 2. Specifications

Model	EL540
Input Port	Micro-USB
Rated Input	DC5V / 1A Max.
Output Port	Dual USB (Type A)
Rated Output	Output I - DC5V / 1A Max. Output II - DC5V / 2.1A Max.
Dimension	93 x 71 x 29 mm
Weight	≤ 246g
Operating Temperature	0°C - 40°C
Charging Time	Approx. 8.5 hrs.
Cycle Life	≥ 700 times

## 3. Product Illustration



## 4. Charge the Power Bank

### I. Charge the Power Bank via Computer USB terminal

1. Connect the provided USB power cable and the micro-USB plug connector tip (the tip with a symbol "M10") together.



2. Insert the micro-USB plug of the accessory cable into the Power Bank input port.
3. Insert the USB type A plug of the accessory cable into a USB port of the desktop or laptop computer.
4. During charging, the 5-level LED indicator will flashing grow and the LED will glowing in number corresponding to charge time.
5. When the Power Bank is fully charged, those 5 LEDs will all glow.

### II. Charge the Power Bank via your original digital device's AC power adaptor, which is 5V output and with micro-USB output plug

1. The AC power adaptor should be met below requirements:
  - Output voltage: DC 5V
  - Output plug: Micro-USB
2. If all the conditions are satisfaction, charge the Power Bank similar as the above method I.

## 5. Charge your Digital Device


1a. Use the provided USB power cable and connector tips




OR



- 1b. Use the proprietary USB connection cable which is sold together with your device.
2. Insert the USB type A plug into the Power Bank output port.
3. Insert the connection cable's output plug to the device.
4. Press the Functional Switch to start charging.



5. The dual USB output ports can charge two digital devices simultaneously.



\*High power output, special for Tablet PC

## 6. LED Flashlight

1. Keep pushing on the Functional Switch 3 seconds will turn the LED flashlight on.
2. Push again the Functional Switch 3 seconds to turn off the LED flashlight.

## 7. Caution

- Do not disassemble, refit or recombine it by yourself.
- Do not throw, knock, shake or strike it.
- Do not put it in the water, keep the battery dry, and far away from rainwater, moisture and erosive materials.
- Avoid sunshine or rain and it can store in a dry place with a proper ambient temperature.
- Do not place or carry inflammable, explosive and hazardous articles near the battery.
- Do not short circuit the battery.
- When this battery is disused, please discard this product and its accessories in accordance with related local environmental protection laws and regulations.
- Do not clean the battery with stimulating chemicals, washes or detergents with relatively high density. Use soft cloth to lightly dip soap solution containing no harmful materials, and clean the battery.
- Please recharge this battery once three months when it is not used for long time.